

<p>1) Remove the screw from the tapped bushing; hold a finger on the head of the bushing as shown on picture #1. To loosen the screw you have to turn <u>counterclockwise</u>.</p>	<p>2) Place the screw from the plastic bag in the mounting hole of the nylon fitting and place the nylon fitting on the tube; remember to have the milled groove up so the hole for the locking spring is to the right as shown on picture #2.</p>
	
<p>3) When you tighten the screw in the tapped bushing you hold the nylon fitting and the bushing fixed with your left/right hand as shown on picture #3. To tighten the screw you have to turn <u>clockwise</u>.</p>	