



Important information:

- Please retain these instructions for future reference
- Do not allow the product to come into contact with water or other liquids.
- The safety isolating transformer to be used with the light panel should be regularly examined for potential hazards such as damage to the cable, cord, plug, enclosure or other parts. In the event of any damage, the light panel must not be used until the damage has been properly repaired.
- The colour changing light panels are not intended for children under 3 years old.
- The transformer is not a toy.
- The light panel must only be used with the recommended transformer.
- The light panels are to be disconnected from the transformer before cleaning.




Colour changing light panels



Colour changing light panels are a fantastic and engaging resource. Children will love to explore colour mixing, transparency and interactions with natural materials.


Getting started:

Connect the d.c. jack to the power socket and plug the power supply into a mains socket to switch on the light panel. All the functions can now be accessed using the infra-red remote control.



Using the remote control:

Before using ensure that the insulating tab is removed from the battery compartment



Modes:

- Flash** 7 different colours.
- Strobe** Smoothly changes brightness of white.
- Fade** Smoothly changes through all the colours of the rainbow.
- Smooth** Automatically steps through red, green and blue

When using any of the modes, the brightness control can be used to change the transition rate.

If you do not get the colour expected, press the "off" button. Now press the "smooth" button. The light panel will flash. Switch the light panel on and press the red button. If the colour is still incorrect, just repeat the process until it is correct.

WARNING:

OBSERVE ALL NECESSARY PRECAUTIONS FOR STROBE ILLUMINATION! Take care to ensure that no user, or observer of the light panel is adversely affected by stroboscopic light.

Cleaning

To Clean, use a soft damp cloth. Under no circumstances use solvents or abrasives to clean the product.

Warranty

This colour changing light panel is guaranteed for a period of one year from the date of delivery to the customer. This warranty does not apply to defects resulting from the action of a user such as misuse, improper maintenance or repair, or unauthorized modification.