

# Class headphones

Replacement leads and ear cushions are available from Hope Education



## Replacing the ear cushions:

The ear cushion is held in place by six clips. Gently unclip the ear cushion as shown. Replace the ear cushion and clip back into position.



## Replacing the lead:

Simply unscrew the connector from the headphones by turning the connector anti-clockwise until the jack plug is released. The new lead is inserted and the connector rotated clock-wise until finger tight.



## Using the converter:

If required, the 3.5 mm jack can be converted to 1/4". Insert the 3.5mm jack into the converter and turn clock-wise until finger tight.

## Specification:

- Impedance: 32 Ohms
- Frequency Response: 20 – 20KHz
- Sensitivity: 118dB +/- 3dB
- Max. Input Power: 15mW
- Cable length: 1.5m braided cable
- Plug: 3.5mm stereo nickel-plated plug with 6.3mm adaptor



*Inspire · Create · Educate*



Manufactured in China for Hope Education  
Gregory street, Hyde, Cheshire, SK14 4RH, UK