



*YOUR BEST SHOT !*

SURE SHOT  
**PORTABLE COURT SYSTEM**  
**MODEL 510**  
ASSEMBLY INSTRUCTIONS

**FAILURE TO READ INSTRUCTIONS COMPLETELY BEFORE  
ASSEMBLY COULD RESULT IN SERIOUS INJURY !!!**

BEFORE BEGINNING ASSEMBLY READ INSTRUCTIONS  
COMPLETELY AND CHECK TO SEE IF ALL PARTS WERE  
INCLUDED USING THE PARTS LIST PROVIDED.



**WARNING !!!**

TO PREVENT THE PORTABLE COURT  
SYSTEM FROM TIPPING. DO NOT ATTEMPT  
TO STAND THE UNIT UP WITHOUT FIRST  
FILLING THE BASE WITH SAND.

THE UNIT COULD FALL OVER WITHOUT SAND  
IN THE BASE THIS COULD CAUSE DAMAGE  
OR INJURY

DO NOT ALLOW CHILDREN TO ADJUST.  
CLIMB ON OR HANG FROM ANY PART  
OF UNIT.

DO NOT PERFORM SLAM - DUNK PLAY  
ON THIS UNIT

THE PORTABLE UNITS ARE NOT DESIGNED  
FOR THIS TYPE OF EXTREME USE.

DO NOT USE THE UNIT DURING WINDY  
CONDITIONS

# PART LIST

P1



P2



P3



P4



P5



P6



P7



P8



P9



Angle Bracket  
38x33x4mm

A



45x8mm

B



25x8mm

C



38x8mm

D



110x8mm

E



8mm U-Bolt

F



Plastic Cap  
for nut  
Qty. 8 Nos.

G



Pipe Top Cap

H



Steel Strip  
with two holes  
45x35mm  
Qty. - 2 Nos.

I



Steel Strip  
with one hole  
45x35mm  
Qty.- 4 Nos.

J



Ground Anchor  
125x8mm


K




Ground Anchor Sleeve

## POLE INSTRUCTIONS


BE SURE TO CORRECTLY IDENTIFY THE POLE SECTIONS  
BEFORE BEGINNING ASSEMBLY



TOP POLE SECTION



MID POLE SECTION




BOTTOM POLE  
THREE ROUND HOLES  
AT THE BOTTOM  
AND TWO ROUND  
HOLE AT THE MID  
POINT

## Required Material and Tools

- |                      |                                   |
|----------------------|-----------------------------------|
| 1. 8×25kg sand bags  | 4. 13mm Wrench/socket             |
| 2. Adjustable wrench | 5. Large screwdriver              |
| 3. Hammer            | 6. 2 block wood approx. 10×10×3cm |

**NOTE** : Bolt kit check list is included in the bolt kit. Be sure to check contents prior to assembly. **(Two men required for assembly)**



**STEP-1** Insert the rod through wheels and bottom pole holes with base (P1).

### **STEP-2**

Attach support tubes P7 at the both side of the base (P1) using nut & bolt A-45×8mm & use two holes strip (H) as a washer under the base



### **STEP-3**


Attach both other side of tube (P7) with lower pole using nut & bolt (D-110×8mm) & tighten it with the help of two spanners

### **STEP-4**

Fill the base (P1) with water or sand

#### **Warning**


This unit can hold 120 Liters of water instead of sand. In case of using water make sure that base P1 is close properly with ring gasket inside the cap. In case of using water strongly advice to control the tightness of the base every time you are going to play.





## **BEFORE CONTINUING ASSEMBLY**

Backboard and goal should be assembled at ground level.  
Assembly at top of pole could result in injury.



### **STEP-5**



Insert bolt (C) through top holes of back board to attach angle bracket (P9) at the back side of the back board.





### **STEP-6**

Insert 8mm U-bolt (E) through (P8) and back board. Attach ring (P2) from front side of back board with U-bolt (E).


Note: Do not tight the nut.



**STEP-7** Attach long steel strip (P4) with (P8) & (P9) using nut & bolt (B).



**STEP-8** Attach top pole with middle pole to attach with lower pole which is attach to base (P1) using block wood & hammer



**STEP-9** Bring down the pole to insert U-bolt (E) with top pole and tighten the nut with the help of spanner of the U-bolt attached with ring.




**STEP-10** Attach support strip (P5) with lower pole attached to (P1) using nut & bolt (D) and tighten it with the help of spanner.



**STEP-11**

**FOR ADDITIONAL STABILITY**


Locate the unit at desired playing location. Start the installation of the ground anchor (J-125×8mm) by hand approximately 8cm behind unit. Finish installing the anchor by inserting large screw driver into the eye of the anchor and twisting until only the eye is remaining above ground.




Note : The anchor bolt should go through part (P5), (P1) and steel strip (I).



Use the large loops of the net install onto the ring "no-ties"





Cover the top pole with plastic cap (G)



cover all the nuts with plastic cap (F) before pole is in playing position







### **POLE MAINTENANCE**

Periodically wipe down pole with a damp cloth to remove dirt, pesticides, herbicides, etc. This routing will prolong the life of your pole.  
If your pole becomes scratched and rust begins to appear, repair by using rust proof gloss black paint ( follow instructions on paint can).

**THANK YOU FOR BUYING SURE SHOT !!!**